



sofaforma

ASSEMBLY INSTRUCTIONS

DINING CHAIR PUMA				
DESCRIPTION		MEAS.	QTY	SKETCH
F	ALLEN KEY	Ø6	1	
E	ALLEN SCREW	Ø6*25	4	
D	WASHER	Ø6	4	